


How Riveting a GO-Nut ?



Riveting Tool Operation Instruction


GO-10-SP



GO-10-SP



How Riveting a GO-Bolt ?



How Changing Mandrel+Anvil/Puller?

