


## How Changing Mandrel+Anvil/Puller?



Weight	L	H	P	Ø
0.72kg	134mm	265mm	43mm	16

TELEFON: +49 - (0) 211 - 24 50 00 - 0 / TELEFAX: +49 - (0) 211 - 24 50 00 - 250  
 e-mail: [info@blindniete.org](mailto:info@blindniete.org) / Internet: [www.blindniete.org](http://www.blindniete.org)




## Riveting Tool Operation Instruction


### GO-6-N



**GO-6-N**



### How Riveting a GO-Nut ?



### How Riveting a GO-Bolt ?

