


## Tool Capacity:

Rivet Dia. Metric [ mm ]	Rivet Dia. Imperial [ inch ]	Rivet Size Number Imperial	Identification Remarks on Nosepiece	Remarks
3,0/3,2	1/8	4	B	standard
4,0	5/32	5	C	standard
4,8/5,0	3/16	6	D	standard
6,0	---	---	E	standard
6,4	1/4	8	F	standard




Weight	L	H	P	Ø
2.3kg	500mm	171mm	57mm	24



## Riveting Tool Operation Instruction


### GO-8




TELEFON: +49 - (0) 211 - 24 50 00 - 0 / TELEFAX: +49 - (0) 211 - 24 50 00 - 250  
 e-mail: [info@blindniete.org](mailto:info@blindniete.org) / Internet: [www.blindniete.org](http://www.blindniete.org)



### How Riveting a Rivet ?



### How changing of Nosepieces ?



*A set of nosepieces screwed on the handle of the tool.*

### How Replacing Used Jaws ?

